

## QUICK-LOCK Adapterplatte universal QUICK-LOCK Adapter Plate universal

### Montagehinweise

Alle vom Motorrad gelösten Schrauben sind gemäß Herstellerangaben wieder zu montieren, oder mit von SW-MOTEC gelieferten Schrauben zu ersetzen. Falls nicht anderweitig definiert, diese Schrauben nach Tabelle anziehen.

M6	4,5 Nm
M8	8,0 Nm

Gegebenenfalls Schrauben mit flüssiger Schraubensicherung einkleben.

Prüfen Sie nach 50 km alle Verbindungen auf festen Sitz.

SW-MOTEC GmbH & Co. KG  
Bahnhofstrasse 44d  
35282 Rauschenberg  
-Germany-

Tel.: ++ 49 (0) 6425 816 800  
Fax: ++ 49 (0) 6425 816 810

[www.sw-motech.com](http://www.sw-motech.com)

### Mounting Instructions

SW-MOTEC products should be installed by a qualified, experienced motorcycle technician. If you are unsure of your ability to properly install a product, please have the product installed by your local motorcycle dealer. SW Motech takes no responsibility for damages caused by improper installation.

All screws, bolts and nuts, including all replacement hardware provided by SW-MOTEC, should be tightened to the torque specified in the OEM maintenance manual for your motorcycle. If no torque specifications are provided in the OEM maintenance manual, the following torques may be used:

M6	4,5 Nm
M8	8,0 Nm

All screws, bolts and nuts should be checked after driving the first 50 km to ensure that all are tightened to the proper torque.

Medium strength liquid thread-locker (i.e., "Locktite") should be used to secure all screws, bolts and nuts.

1 Adapterplatte  
Adapter Plate



GPT.00.152.044 00

Anzahl/ Pcs. 1

2 Schnellverschluss  
Quick Fastener



CAM.00.50E8-17Z

Anzahl/ Pcs. 3

4 Haltenocken  
Cam-Lock



CAM.00.V50R3-1-1AF

Anzahl/ Pcs. 3

3 Sicherungsring  
Retaining Ring



CAM.50E2-3BP

Anzahl/ Pcs. 3

5 Gewindefurchende  
Schraube  
Self Tapping Screw



M3 x 6 GEFU

Anzahl/ Pcs. 6

