

UNIVERZÁLNÍ ROZŠÍŘENÍ ZRCÁTEK Mirror Extension Universal

Montážní návod

Montáž tohoto produktu může být komplikovaná a vyžadovat dobré technické znalosti, pokud si nejste jisti, navštivte specializovanou dílnu. SW-MOTECH nenesе žádnou odpovědnost za škodu způsobenou nesprávnou montáží.

Všechny šrouby a matice by měly být dotaženy podle utahovacího momentu, který je uveden v OEM příručce motocyklu. Pokud tomu tak není, použijte následující utahovací momenty.

Použijte středně silné lepidlo na závity.

Po ujetí 50 km zkontrolujte dotažení všech šroubů a matic.

M10 46 Nm

SW-MOTECH GmbH & Co. KG
Erteweg 8/10
35282 Rauschenberg
Germany

Tel. +49 (0) 64 25/8 16 8-00
Fax +49 (0) 64 25/8 16 8-10

info@sw-motech.com
www.sw-motech.com

Mounting Instructions

SW-MOTECH products should be installed by a qualified, experienced motorcycle technician. If you are unsure of your ability to properly install a product, please have the product installed by your local motorcycle dealer. SW-MOTECH takes no responsibility for damages caused by improper installation.

All screws, bolts and nuts, including all replacement hardware provided by SW-MOTECH, should be tightened to the torque specified in the OEM maintenance manual for your motorcycle. If no torque specifications are provided in the OEM maintenance manual, the following torques may be used:

M10 46 Nm

All screws, bolts and nuts should be checked after driving the first 50 km to ensure that all are tightened to the proper torque.

Medium strength liquid thread-locker (i.e., "Loctite") should be used to secure all screws, bolts and nuts.

Subject to change. Not responsible for typos.

VÝHRADNÍ ZASTOUPENÍ PRO ČESKO A SLOVENSKO

SUMOTO spol. s.r.o.
Cacovická 8
614 00 Brno
Česká Republika

Tel.: +420 545 211 913
mail: sumoto@volny.cz
web: www.sumotobrna.cz

